

Martindale Abrasion Tester - Smartindale



(The picture is for reference only)

Application:

Martindale Abrasion Tester - Smartindale is designed for fabric abrasion and pilling tests. It uses a digital algorithm to generate a Lissajous curve and then drives the friction mechanism, ensuring precise operation without the need for calibration. You can effortlessly switch between test modes, such as from the abrasion test to the pilling test, with a single click, without having to change any pins.

Specifications:

Power	220/110V 50/60Hz
Weight	90kg
Dimension	510*850*300 mm(W*L*H)
ABRASION TEST	
MAX STROKE OF MOVEMENT	60.5+/-0.5mm
WEIGHT OF HOLDER AND SPINDLE	198+/-2g
PILLING TEST	
MAX STROKE OF MOVEMENT	24+/-0.5mm
WEIGHT OF HOLDER AND SPINDLE	155+/-1g

FOCUS IN MATERIAL TEST

KASONTTEST®

**JINAN KASON TESTING
EQUIPMENT Co, LTD.**

DuandianIndustrial Park , Jingshi Road, Jinan City,China.

P: +86 159 1008 1986

E: admin@jnkason.com | **W:** www.syjlab.com

